
Technical Preview of the United States Demonstration of an Attribute Measurement System with Information Barrier

Rena Whiteson
Los Alamos National Laboratory



The AMS/IB




The Shielded AMS/IB







Shielded Electronics Rack




Detector Control Box Controlled by Operator

Background
Measurement Control
Gamma Calibration
Assay





Computers



- Boot off PROMS
- For assay:
 - No monitors
 - No keyboards

- potentially contains classified data
- unclassified data in protected area
- barrier elements
- unclassified data in open area



Computers

	PC104 CPU	DOS Version	Application Language
			MS Visual C 1.52
Pu300/600 Analyzer	EMAC SBC-4335	MS-DOS 6.22	MS FORTRAN 90
			MS Visual C 1.52
Pu900 Analyzer	EMAC SBC-4335	MS-DOS 6.22	MS FORTRAN 90
			MS Visual C 1.52
Symmetry Analyzer	EMAC SBC-4335	MS-DOS 6.22	MS FORTRAN 90
NMC Analyzer	Ampro CoreModule 3SXi	ROM DOS 6.22	MS Visual C 1.52
	•		
Computational Block	Ampro CoreModule 3SXi	ROM DOS 6.22	MS Visual C 1.52


Computational Block

- Holds threshold values
- Performs comparisons, determines pass/fail for each attribute
- Memory is volatile or read only
- Test-complete signal
- Error signal



Computational Block

PROM



Output to Data **Barrier**

Input from 4 Analyzers





Computational Block Memory

- PROM nonvolatile memory (Atmel 27C080)
 - —contains executable program
 - —read-only memory, cannot be written to
- CMOS disabled, no battery
- RAM 4 MB of volatile memory
- Flash ROM nonvolatile system BIOS memory
 - —write-disabled with pin 11 lifted or Jumper W2 missing
- EEPROM nonvolatile memory, can be written to
 - —necessary for system configuration information
 - —minimum data storage (256 bytes)



Measurement Type: Classified or Unclassified

- Measurement type is determined by the container
- No input from operator
- Detector empty

Classified measurement


Unmodified ALR-8 in detector

Classified measurement

Modified ALR-8 in detector Unclassified measurement



Security Switches



Container for Classified Component: ALR-8





Authentication Container: Modified ALR-8








Authentication Container






Security Switches


System Secure—No Container Closed/Open



System Secure—Unmodified Container
Open/Closed



System Open—Modified Container
Closed/Closed






Security Watchdog

- Security Watchdog controls power to all other elements of AMS/IB.
- If any shielded enclosure is opened, power is immediately removed from the rest of the AMS/IB and all data are purged.
- In open mode, power is restored after a delay.
- Authentication occurs in open/unclassified mode.
- SCRAM switch will remove all power and purge all data from the system at any time the operator demands it.



Security Watchdog

Power Filters




Power Outlets



Power In

Data Barrier


- Controls flow of data across the IB.
- Outputs 1 bit of data per input line.
- Extra layer of defense between red and green.





Data Barrier

Fiber Optic Output






Display

- Receives unclassified data from the data barrier, via fiber optic coupling
- Eight paired red-light/green-light outputs
- Controlled by computational block
 - Six attributes (12 possible results)
 - Measurement Complete/Failure (2 possibilities)
- Controlled by Security Watchdog
 - Security Mode (2 possible modes)
- No data logging



Display





Display

